

Miniaturization of High Sensitivity Laser Sensing Systems

Damien Weidmann

Outline

- Drivers for miniaturization
- Molecular fingerprinting in the Mid IR
- Optical integration technologies
- Forward looking examples
- Conclusion


Miniaturization Drivers

The small sat disruption

- Low cost
- Rapid development cycle
- Heritage building
- Less risk aversion
- Constellations
- Hands on training
- Lower barrier to entry for small businesses



400 micro satellites annually in 2020 +




Miniaturization Drivers

The small sat disruption

- Low cost
- Rapid development cycle
- Heritage building
- Less risk aversion
- Constellations
- Hands on training
- Lower barrier to entry for small businesses





Small Satellite Mission Type



Miniaturization Drivers


Planetary landers



Sample Analysis at Mars (SAM)



Phoenix lander






InSight lander



Principles of Molecular Sensing

High spectral resolution for fingerprinting

Stretching - Vibration mode ν_3 - 3157 cm^{-1}




Bending - Vibration mode ν_4 - 1367 cm^{-1}



- Narrow window sufficient
- Sounding optimization
- Information from a resolved line
 - Altitudinal information
 - Non LTE effects
 - Velocity
 - EM field information
 - Isotopologue discrimination

Rationale for Mid-Infrared Sensing





Fundamental ro-vibrational molecular absorption bands

Absorption cross sections much greater




8-12 μm and 3-5 μm atmospheric window

Less scattering


Mid IR Key Components



Quantum Cascade Laser



Hg Cd Zn Te Photodiode





QCL advantages include:

- Frequency tailoring
- High power
- Single mode operation
- Ambient T operation
- Frequency tunable
- Good beam quality
- Fast modulation
- Long wavelengths
- Compact and robust

Micro-cooler if 80K operation required




Multimode Hollow Waveguide



$$T_{pq_{dB}} = -4.35 \frac{\lambda^2}{w^3} \left[p^2 \operatorname{Re} \left(\frac{1}{\{(n-ik)^2 - 1\}^{1/2}} \right) + q^2 \operatorname{Re} \left(\frac{(n-ik)^2}{\{(n-ik)^2 - 1\}^{1/2}} \right) \right]$$


Hollow
waveguide
channels




Prof. Mike Jenkins

HOLLOWGUIDE LTD

Optical Integration & Tolerancing




angular misalignment




design criteria

$$\theta \leq \frac{\lambda}{5w}$$

lateral misalignment



$$\chi \leq \frac{w}{15}$$




Prof. Mike Jenkins



HOLLOWGUIDE LTD

Building Blocks


Study and modelling of individual functions



Opto-acoustical device
HW in ceramic



Mini-asphere




HW in metal



Beam-splitting


Laser coupling




Laser alignment



Fibre coupler




First Miniature LHR Demonstration




- Spectral Resolution: 0.002 cm^{-1}
- NESR $120 \text{ nW/cm}^{-2} \cdot \text{sr} \cdot \text{cm}^{-1}$
- Power $< 10 \text{ W}$

First Miniature LHR Demonstration






- Spectral Resolution: 0.002 cm^{-1}
- NESR $120 \text{ nW/cm}^{-2} \cdot \text{sr} \cdot \text{cm}^{-1}$
- Power $< 10 \text{ W}$
- Spectral range : 10 cm^{-1}



- Spectral Resolution: 0.002 cm^{-1}
- Spectral range : 4000 cm^{-1}

Atmospheric Sounding From Landers

Ground solar occultation



Benefits:

- Measurements throughout Martian day
- Temporal resolution (1 meas/min)
- High VMR sensitivity
- Some vertical profiling

MISO mission

Methane Isotopologues by Solar Occultation

Technology push



In orbit demonstration mission of:

- LHR spectrometer and component
- Dual band high res isotope sensing
- Hollow waveguide miniaturization technology
- Solar occultation limb from a small sat

Science pull

Study the methane cycle and its change through:

- Component to a methane observing system
- Constraining further the methane budget and cycle
- UT/LS transport
- Improved emission estimates



Conclusion


- Mission-enabling technology
 - Mid IR Laser spectroscopy in space
 - Instrument with unprecedented size/performance ratio
- Genuine platform technology for molecular sensing
 - Atmospheric sensing
 - Passive spectrometers, lidars, In-situ sensors
 - Laser communications
 - Miniaturized transmitters / receivers
 - Laser occultation in formation flying
 - In flight diagnostics laser systems
 - Many terrestrial applications to benefit as well
- Next is to shrink further : mid IR photonics

Acknowledgements

➤ Collaborators



- Helen Butcher
- Neil Macleod
- RAL Space PDF
- Mike Jenkins
- Russ Boyce
- Doug Griffin

➤ Funding




Shrinking Further : Mid IR Photonics


Novel mid IR glasses and photonic structures



Ultra-Fast Laser Inscribed
GLS waveguide




Input facet





Experiment and modelling

Modelling of novel structures
Evanescent X coupler




Modelling of optical feedback
impact



Optimum Coupling Assessment



Far field profiles (0.750 mm guide width)

Lateral coupling : sensitivity $< 2 \mu\text{m}$



QCL output
 $4 \times 10 \mu\text{m}^2$

HW input $\sim 0.75 \times 0.75 \text{ mm}^2$



Waist position sensitivity $< 10 \mu\text{m}$

